


## PS1A: Single columns of poster holders ceiling-suspended on wires

### **FIXING INSTRUCTIONS - CEILING-SUSPENDED WIRES**

Screw into ceiling using appropriate fixings for ceiling material  
(fixings not supplied - choose appropriate )

**NOTE** that all weight of a suspended display is supported by the top fixings, which therefore need to be firm fixings into a substantial ceiling.



1. Mark the required positions of the wire top fixings on the ceiling. The table on page 2 shows the wire centres required for the different standard sizes of poster holders.

**For each wire:**

2. Fix the brass inner top fixing to the ceiling in its marked position using appropriate fixings (not supplied).
3. Screw the outer top fixing, with the crimped end of the cable inside, on to the inner top fixing.
4. (Repeat steps 3 - 4 until all wires have been fitted).

**PS1A: Single columns of poster holders ceiling-suspended on wires**

**FIXING INSTRUCTIONS - CLAMP-ON POSTER HOLDERS**

FIX HOLDERS TO WIRES:

For each poster holder:

1. Use the allen key provided to loosen the grub screws in the wide slot in each clamp so that the acrylic holder can be positioned in the slot.
2. Fit two clamps to each side of the poster holder in the desired positions, using the allen key to tighten the grub screws when the holder is in position.
3. Remove the grub screws from the narrower slot in each clamp so that the wires can slide into these.
4. Position the holder between the wires, and screw the grub screws back into the clamps to fix the holders loosely in position, but still allowing it to slide.
5. Slide the holder to its required position and tighten the clamps on to the wires on one side.
6. Use a spirit level to ensure that the holder is horizontal, then tighten the grub screws on the other side.

**WIRE CENTRES FOR SUSPENDED POSTER HOLDERS**

| POSTER HOLDER SIZE | A5 landscape<br>A4 portrait | A4 landscape<br>A3 portrait | A3 landscape<br>A2 portrait | A2 landscape<br>A1 portrait | A1 landscape<br>A0 portrait | Double A4 portrait                | Triple A4 portrait                 | Double A4 landscape<br>Double A3 portrait | 20"x30" portrait | 20"x30" landscape<br>30"x40" portrait |
|--------------------|-----------------------------|-----------------------------|-----------------------------|-----------------------------|-----------------------------|-----------------------------------|------------------------------------|---|------------------|---------------------------------------|
| WIDTH OF POSTER    | 210mm                       | 297mm                       | 420mm                       | 594mm                       | 841mm                       | 2x<br>210mm<br>(12mm gap between) | 3x<br>210mm<br>(12mm gaps between) | 2x<br>297mm<br>(12mm gap between)         | 508mm<br>(20")   | 762mm<br>(30")                        |
| WIDTH OF HOLDER    | 234mm                       | 321mm                       | 444mm                       | 618mm                       | 865mm                       | 456mm                             | 678mm                              | 630mm                                     | 532mm            | 786mm                                 |
| CENTRES FOR WIRES  | 244mm                       | 331mm                       | 454mm                       | 628mm                       | 875mm                       | 466mm                             | 688mm                              | 640mm                                     | 542mm            | 796mm                                 |